

43.5

2 × R2.5

4.5

SH-302

382

REV FWD

MODE SET

DANGER:Risk of injury and electric shock

- ▲ Read the manual and follow the safety instructions before use
- ▲ Isolate from supply and wait 10 minutes before removing this cover
- ▲ Ensure proper earth connection

CAUTION:Risk of fire

- ▲ Mount the inverter on a non combustible surface

危险：可能导致伤害和触电



- ▲ 安装运转之前请详细阅读说明书，并按指示操作
- ▲ 通电中或切断电源后10分钟内请勿打开上盖
- ▲ 请确保可靠接地

注意：可能导致火灾

- ▲ 请安装于金属等不燃物上

W

W1



Unit : mm						
Type	H (mm)	H1 (mm)	H2 (mm)	W (mm)	W1 (mm)	D (mm)
SS2-021-1.5K	174	165	51.5	110.5	58	134
SS2-021-2.2K						
SS2-023-2.2K						
SS2-023-3.7K						
SS2-043-2.2K						
SS2-043-3.7K						